

*Telegrapher*



**USER MANUAL**

**GORILLA**

*Telegrapher*

TELEGRAPHER LOUDSPEAKERS

HAND MADE WITH LOVE IN ISTANBUL

SERIAL NO

INSPECTED BY

We take great pride in our work,  
and we hope these monitors allow you  
to realize your audio endeavours  
at the very highest level.

# ABOUT GORILLA

Gorilla is an analog mid-field monitor designed for critical mixing and mastering applications.

# SAFETY PRECAUTIONS

Your speakers operate at mains voltage and carries hazardous voltages.

Do not expose your speakers to rain, water or moisture to reduce the risk of fire or electric shock.

Do not place your speakers near any heat sources such as amplifiers that produce heat.

Make sure electrical power is off before connecting or disconnecting power and/or signal cables.

Avoid direct sunlight.



This symbol indicates that this product should not be disposed of with your household waste.

Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances.

For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, or your household waste disposal service.

# Operating Voltage

Min Voltage: 100-120 Volts AC  $\pm 10\%$

Max Voltage: 200-240 Volts AC  $\pm 10\%$

Voltage Frequency: 47 - 63 Hz

Connector: 3-pin IEC 250 Volts AC, 10A male

Input power: 800W max



This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure, that may be of significant magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user of the presence of important operating and maintaining (servicing) instructions in the literature accompanying the appliance.

# Dimensions

318 x 450 x 275

all dimensions are in mm (H x W x D)

# Weight

27 Kg each

# Amplifiers

Tweeter	100 Wrms
Mid	350 Wrms
Woofers	350 Wrms

Load-Independent Frequency Response  
Frequency-Independent THD  
Over Current / Thermal Protection  
Auto Standby

Tweeter: 2.5 cm coated textile diaphragm  
Patented Symmetrical Drive (SD-2)

Mid: 12 cm paper cone  
Patented Symmetrical Drive (SD-3)

Woofer : 22 cm aluminium cone  
Patented Symmetrical Drive



LEFT

RIGHT

The tweeters should stay inside  
of your listening point.

LET'S GET STARTED!

# INPUT

---

1

SELECT XLR  RCA

STAND BY ON  OFF

A



1: SHIELD  
2: HOT  
3: COLD

BALANCED



UNBALANCED

2

B

# 1 SOURCE SELECTION

- Please use the input select button at the back panel to choose your input.
- You can use balanced XLR cable and unbalanced RCA cable.

INPUT

---

● SELECT XLR ● RCA ●

● STAND BY ON ● OFF ●

## 2 STAND BY ON/OFF

- Using the selection button at the back panel, set your stand by on or off.
- The Gorilla turns off after 120 mins if the stand by function is on and there is no signal.

INPUT

---

● SELECT XLR ● RCA ●

● STAND BY ON ● OFF ●





# RCA

## Unbalanced Analog Input

Sleeve: Shield (Ground)

Tip: Positive (+ or hot)

Input impedance: 300 kOhm

Nominal level: TBD



# SERVICE

Modifications by any persons other than  
Telegrapher Loudspeakers authorized personnel  
voids the warranty!



Do not leave your loudspeakers on  
at night unmonitored!

Turn off after use!



# PROTECTION

The Gorilla has four protection circuits.

If the maximum temperature is reached, the amplifiers are switched off to protect from damage. Additionally the red protection led on the front will be enabled.

Also if a critical electrical failure or high frequency signal (like microphone feedback) is detected, the amplifiers are shut down immediately and the red protection led on the front will be enabled.

In this case, unplug the power cord, wait for the back panel cool down and red light go off (usually 3 minutes), plug the power cord and power on the Gorilla.

The Gorilla should resume normal operation. If not, please contact Telegrapher Loudspeakers.

# CLIPPING


If the amplifiers are clipping, the front red led will blink rapidly to warn you.

Please lower your input signal until you don't see the blinking red led.  
At normal operation you should see the white led on.

In case of too much clipping, the amplifiers will be shut  
down to protect your gear.

In this case, unplug the power cord, wait for the red light go off  
(usually 3 minutes), plug the power cord and power on the Gorilla.

The Gorilla should resume normal operation.



# TROUBLESHOOTING

**NO POWER** Check the power outlet.

The internal fuse may be blown. This fuse is not user replaceable. Please contact Telegrapher Loudspeakers for more information about service and repair.

**NO SOUND** A protection might be triggered. Is the module overheated? Try cycling the mains power.

Check the source signal.


Check the cables.

# SUPPORT

We will be happy to assist you!

The latest manuals, datasheets and some fun stuff can be found in our web site.

You can also contact us for any questions using the form on our web site.



# CONNECT WITH US

 [www.telegrapherloudspeakers.com](http://www.telegrapherloudspeakers.com)

 telegrapherloudspeakers

 telegrapherloudspeakers

## LIMITED WARRANTY

Telegrapher Loudspeakers warrants this device for a period of two years after the original date of purchase against defects due to faulty workmanship or materials arising from normal use of the device. The warranty covers working parts that affect the function of the device. It does NOT cover cosmetic deterioration caused by fair wear and tear, or damage caused by accident, misuse, neglect or transporting. Any attempt to modify or take apart the device or screws will void the warranty.

If you discover a defect, notify Telegrapher Loudspeakers during the warranty period. Claims under warranty must be supported by reasonable evidence that the date of the claim is within the warranty period. To validate your warranty, please keep your original purchase receipt together with these warranty conditions for the duration of the warranty period. Replacement products claimed under warranty are not entitled to renewed 2-year warranty coverage.

Date of purchase,  
Seller's Stamp & Signature  
(Should be filled by seller)

*Telegrapher*

TELEGRAPHER LOUDSPEAKERS

